

Integra Elevator Priority Mode

Software License

The purpose of the Integra Elevator Priority Mode is to ensure that transportation of dangerous substances can be done in a safe and controlled way.

Performance

Facilities that are using elevators to transport dangerous or contagious substances are not allowing staff to travel at the same time within the elevator. Therefore they can lock the elevator in priority mode so only the person that put the substance inside can take it out after elevator has arrived to predetermined floor.

Priority Mode is activated/deactivated from card reader inside or outside cabin which controls dedicated output or from Integra Client.

To be allowed to activate/deactivate Priority mode from Client program the operator must have Control and View access rights to Elevator Object.

Priority mode has to be detected by Integra by following input connected to elevator's output.

Article numbers, licenses without agreements

44282125	Software Integra Elevator Priority Mode
----------	---

44292125	Software update License Integra Quarantine Zone
----------	---

Article numbers, licenses with 2 or 3 year agreements

44312125	License Agreement Integra Elevator Priority Mode
----------	--